

CSC 491 / 391
Mobile Application Development for iOS II



Prof. Xiaoping Jia
 School of Computing, CDM
 DePaul University
xjia@cdm.depaul.edu
[@DePaulSWEEng](https://twitter.com/DePaulSWEEng)

1

Motion Sensors

2

Outline

- Sensors & motion events
- Accelerometer
- Gyroscope
- Core Motion
- Sensor fusion



DEPAUL UNIVERSITY

3


Sensors in Mobile Devices

- Convert a wide range of physical measurements into digital signals.
- Built-in sensors on iOS devices
 - Accelerometer – Linear acceleration on 3 axes
 - Gyroscope – Device orientation, rotational velocity on 3 axes
 - Magnetometer – Earth's magnetic field, digital compass (not available on iPods)
 - Barometer – Air pressure, altitude/elevation
 - GPS (Global Positioning System) – Location, i.e., latitude and longitude on Earth
 - Microphone – Ambient sound

DEPAUL UNIVERSITY

4

iOS Device Motion Sensing



APPLICATION PROCESSOR

M8 MOTION COPROCESSOR

Accelerometer
Gyroscope
Magnetometer
Altimeter

DEPAUL UNIVERSITY

5

Why Motion Sensors?

- Your device is aware of its precise motion within its environment
- Controls are no longer limited to the UI widgets on the screen
- Opens the door to a new world of
 - gaming possibilities
 - motion based gestures
 - medical applications
 - other creative uses

DEPAUL UNIVERSITY

6

Core Motion Framework

- Receive and handle motion events
 - Acceleration
 - Rotation rate
 - Orientation
 - Attitude
 - Altitude
 - Step count


DEPAUL UNIVERSITY

7

The Accelerometer

- MEMS (micro-electromechanical system)
- Measure accelerations (in $g \approx 9.81 \text{ m/s}^2$) in each of the three physical axes.
 - Acceleration is the *rate of change* of velocity.
 - *Acceleration of a device = Earth Gravity + User Acceleration*
- Available in all iOS devices, including the very first iPhone
- Low power consumption
- Responsive
- Noisy

DEPAUL UNIVERSITY



8

Acceleration Data


- The accelerometer measures the acceleration of the device (A_d)
- The relation to the forces applied to the sensor (F_s)

$$A_d = - \sum F_s / \text{mass}$$
- The forces include the force of *gravity*

Newton's Second Law of Motion (1687)

$$F = m \cdot a$$

$$1 \text{ N} = 1 \text{ kg} \cdot \text{m/s}^2$$



DEPAUL UNIVERSITY

11

Gravity


- When the device is still, the accelerometer reading is

$$1 g \approx 9.81 \text{ m/s}^2$$

Average Earth gravitational acceleration at sea level
- Separate the gravity

$$A_d = -g - \sum F / \text{mass}$$

User acceleration
- Two software-based sensors
 - *Gravity* – Earth gravitational acceleration
 - *User Acceleration* – Acceleration sans gravity

Galileo Galilei
1564 – 1642

DEPAUL UNIVERSITY

12

The Gyroscope

- A device for measuring and maintaining orientation
- Measure the rotation rate (in radian/s) around each of the three physical axes
 - Radian: standard unit of angular measure

$$1 \text{ rad} = 180^\circ / \pi \approx 57.2958^\circ$$



Gyroscope invented by Léon Foucault in 1852.

DEPAUL UNIVERSITY

14

The Gyroscope

- MEMS sensor
- First appeared in iPhone 4 (2010), also in newer iPod and iPad
 - 3 additional axes of motion sensitivity
 - Awareness of rotational motion
- Responsive
- Precise
- Inherent bias drift



DEPAUL UNIVERSITY

15

Precision, Accuracy, and Bias


- Precision: the closeness of multiple measurements
 - The variability of the measurements
- Bias: the difference between the estimation based on the measurements and the true value
 - The closeness to the true value, i.e., the *accuracy*
- Unbiased = Accurate
- Precise ≠ Unbiased

DEPAUL UNIVERSITY



13

Precision, Accuracy, and Bias – Illustrations



Precise, accurate,
and unbiased


DEPAUL UNIVERSITY

14

16

17

Precision, Accuracy, and Bias – Illustrations




Imprecise, but accurate,
and unbiased

DEPAUL UNIVERSITY

15

18

Precision, Accuracy, and Bias – Illustrations




Precise, but inaccurate,
and biased

DEPAUL UNIVERSITY

16

19

Precision, Accuracy, and Bias – Illustrations



Imprecise, inaccurate,
and biased

DEPAUL UNIVERSITY

17

20

Handling Motion Events



21

21

Motion Events

- High level (coarse-grained) events originating from the accelerometers and gyroscopes
 - Shaking event
 - Device orientation and tilting
- High rate motion events
 - Raw sensor data
- Core Motion Framework
 - All sensors
 - Sensor fusion

DEPAUL UNIVERSITY

19

22

Shake Gesture

- When users shake a device
 - The system determines whether it is a shaking gesture using the accelerometer data
 - If yes, the systems send a shake motion event to the first responder, when the shaking starts and stops
- Handling the shake gesture
 - Become the first responder
 - Motion events are sent to the first responder
 - Unlike touch events, the first responder must be set explicitly
 - Implement the methods responding to motion events

DEPAUL UNIVERSITY

20

23

Become the First Responder

- In the *View Controller* class

Override a read-only computed property

```
override var canBecomeFirstResponder: Bool {
    return true
}

override func viewDidAppear(_ animated: Bool) {
    super.viewDidAppear(animated)
    becomeFirstResponder()
}
```

DEPAUL UNIVERSITY

21

24

Shake Motion Methods

- Implement the motion event handling methods in the first responder – the *View Controller*

```
override func motionBegan(_ motion: UIEventSubtype,
                        with event: UIEvent?) {
    ...
}

override func motionEnded(_ motion: UIEventSubtype,
                        with event: UIEvent?) {
    ... handle shake ...
}

override func motionCancelled(_ motion: UIEventSubtype,
                            with event: UIEvent?) {
    ...
}
```

DEPAUL UNIVERSITY

22

25

Shake Motion Methods

- The `motionBegan` method:
 - When shaking started
- The `motionEnded` method:
 - When shaking stopped, in less than (\approx) 1 second
- The `motionCancelled` method
 - When shaking lasted more than (\approx) 1 second

DEPAUL UNIVERSITY

23

26

Shake Event Type and Subtype

- The `UIEvent` class
- Properties


```
var type: UIEventType { get }
var subtype: UIEventSubtype { get }
```
- Values for the shake event


```
type: UIEventType.motion
subtype: UIEventSubtype.motionShake
```

DEPAUL UNIVERSITY

24

27

Handle Shake Events

- Responding to shake gesture

```
override func motionEnded(_ motion: UIEventSubtype,
                           with event: UIEvent?) {
    if motion == .motionShake {
        label.text = "Shake\ndetected!"
        DispatchQueue.main.asyncAfter(deadline:
            .now() + .seconds(3)) {
            self.label.text = ""
        }
    }
}
```

DEPAUL UNIVERSITY

25

Handle Shake Events

- Simulator
- Hardware
- Shake Gesture

Carrier 10:42 AM

Shake your phone

Shake
detected!

DEPAUL UNIVERSITY

26

28

29

Current Device Orientation

- The `UIDevice` class
 - A singleton: `UIDevice.current`
- Start monitoring device orientation
`UIDevice.current.beginGeneratingDeviceOrientationNotifications()`
- Get orientation
 - Notification for `UIDeviceOrientationDidChange`
 - Use the `UIDevice.current.orientation` property
- Stop monitoring device orientation
`UIDevice.current.endGeneratingDeviceOrientationNotifications()`

DEPAUL UNIVERSITY

27

30

Device Orientation

```
enum UIDeviceOrientation : Int {
    case unknown
    case portrait
    case portraitUpsideDown
    case landscapeLeft
    case landscapeRight
    case faceUp
    case faceDown

    public var isLandscape: Bool { get }
    public var isPortrait: Bool { get }
    public var isFlat: Bool { get }
}
```

DEPAUL UNIVERSITY

28

31

Device Orientation Demo

```
override func viewDidAppear(_ animated: Bool) {
    super.viewDidAppear(animated)
    UIDevice.current.beginGeneratingDeviceOrientationNotifications()
    self.observer = NotificationCenter.default.addObserver(forName: .UIDeviceOrientationDidChange, object: nil, queue: nil) { notification in
        let orientation = UIDevice.current.orientation
        Use orientation ...
    }
}

override func viewDidDisappear(_ animated: Bool) {
    super.viewDidDisappear(animated)
    UIDevice.current.endGeneratingDeviceOrientationNotifications()
    NotificationCenter.default.removeObserver(self.observer!)
}
```

DEPAUL UNIVERSITY

29

32

Device Orientation Demo

```
self.observer = NotificationCenter.default.addObserver(forName: .UIDeviceOrientationDidChange, object: nil, queue: nil) { _ in
    let orientation = UIDevice.current.orientation
    var message = "Orientation: "
    switch orientation {
        case .unknown: message += "Unknown\n"
        case .portrait: message += "Portrait\n"
        case .portraitUpsideDown: message += "Portrait Upside Down\n"
        case .landscapeLeft: message += "Landscape Left\n"
        case .landscapeRight: message += "Landscape Right\n"
        case .faceUp: message += "Face Up\n"
        case .faceDown: message += "Face Down\n"
    }
    if orientation.isPortrait { message += "Is Portrait\n" }
    else if orientation.isLandscape { message += "Is Landscape\n" }
    else if orientation.isFlat { message += "Is Flat\n" }
    message += "Raw value: \(orientation.rawValue)" ...
}
```

33

Orientation

Orientation: Portrait
Is Portrait
Raw value: 1

Orientation: Portrait Upside Down
Is Portrait
Raw value: 2

Orientation: Landscape Left
Is Landscape
Raw value: 3

Orientation: Landscape Right
Is Landscape
Raw value: 4

DEPAUL UNIVERSITY

34

Core Motion Framework

35

Core Motion Framework

- The gateway class: `CMMotionManager`
- Raw data from individual sensors:
 - Accelerometer: `CMAccelerometerData`
 - Gyroscope: `CMGyroData`
 - Magnetometer: `CMMagnetometerData`
- Sensor fusion: `CMDeviceMotion`
 - Processed data from simultaneous tracking of multiple sensors. Sensor fusion algorithms.
 - Device attitude: `CMAttitude`
 - Gravity, user acceleration, and calibrated magnetic fields

DEPAUL UNIVERSITY

36

Core Motion Framework

- Relative altitude
 - Altimeter: `CMAltimeter` `CMAltitudeData`
- Step count
 - Pedometer: `CMPedometer` `CMPedometerData`
- Exercise activities, running, walking, etc.
 - Activity manager: `CMMotionActivityManager`
- Historical motion data
 - Recorder: `CMSensorRecorder`

DEPAUL UNIVERSITY

37

Receive Sensor Data

- Determine the availability of specific sensors
 - Not all sensors are available on all iOS devices
- Set an update interval
 - Hardware update frequency. Max frequency > 100Hz
- Start updates – sensor data becomes available
- Stop updates – when sensor data not needed
- Two approaches to process sensor data
 - Push: receive and process a steady stream of motion data
 - Pull: get and process motion data only when needed

DEPAUL UNIVERSITY

38

Motion Data Update Intervals

- Configurable update frequency (approx. 10–100Hz)
 - Significant impact on resource consumption
- 10–20Hz
 - Suitable for determining the current orientation of the device
- 30–60Hz
 - Suitable for games and other applications that use the accelerometers for real-time user input
- 70–100Hz
 - Suitable for applications that need to detect high-frequency motion
 - For example, you might use this interval to detect the user hitting the device or shaking it very quickly

Especially when pushing

DEPAUL UNIVERSITY

39

Process Motion Data

- Push – receiving updates at specified intervals
 - Provide a handler (closure) to process the updates
 - Core Motion delivers updates to the handler at a constant rate
 - Suitable for data collection
- Pull – periodic sampling of motion data
 - Periodically sample the most recent measurement of motion data, when needed
 - Recommended approach
 - More resource efficient

DEPAUL UNIVERSITY

37

40

Core Motion Gateway – Motion Manager

- Each app should have only a single instance of `CMMotionManager`
- Determine the availability of a hardware sensor
`var isSensorAvailable: Bool { get }`
 where `Sensor` is one of:
`Accelerometer Gyro Magnetometer DeviceMotion`
- Start updates of a sensor
`func startSensorUpdates()`
`func startSensorUpdates(to: queue, withHandler: code)`
- Stop updates of a sensor
`func stopSensorUpdates()`

DEPAUL UNIVERSITY

38

41

Acceleration Data

- Class `CMAccelerometerData`
 - Property
`var acceleration: CMAcceleration { get }`
- Struct `CMAcceleration`
 - Properties:
`var x: Double`
`var y: Double`
`var z: Double`
- Measured in G's (after Galileo Galilei)
 - $1g = 9.81 \text{ m/s}^2 = 32.2 \text{ ft/s}^2$


DEPAUL UNIVERSITY

39

Three-axis accelerometer

Acceleration Data – Direction of Axes

- Core Motion uses the standard 3-axis coordinate system
- Relative to the device's screen in the default orientation
- Never changes when the device is rotated.**
 - The coordinate system for 2-D graphics rotates according to the device screen orientation.



DEPAUL UNIVERSITY

40

43

Gyroscope Data


- Class `CMGyroData`
 - Property
`var rotationRate: CMRotationRate { get }`
- Struct `CMRotationRate`
 - Properties:
`var x: Double`
`var y: Double`
`var z: Double`
- Measured in radians ($\approx 57.2958^\circ$) per second
 - Direction of rotation: Right hand rule

DEPAUL UNIVERSITY

41

Three-axis gyroscope

Rotation Data – Direction of Rotation



DEPAUL UNIVERSITY

42

45

Sensors – Push

- A simple demo app to display sensor data
 - Accelerometer
 - Gyroscope
 - Magnetometer
 - Device Motion
- Using the *push* approach
 - Show sensor readings in text labels

DEPAUL UNIVERSITY

46

Sensors – Push

- The main parts in the *View Controller*

```
import UIKit
import CoreMotion

class ViewController: UIViewController {
    let motionManager = CMMotionManager()
    must be declared as a property

    override func viewDidLoad() { ... }
    override func viewDidAppear(_ animated: Bool) { ... }
    override func viewWillDisappear(_ animated: Bool) { ... }
    ...
}
```

DEPAUL UNIVERSITY

47

Sensors – Push

Determine Sensor Availability

```
override func viewDidLoad() {
    super.viewDidLoad()
    var s = ""
    if motionManager.isAccelerometerAvailable { s += "A" }
    if motionManager.isGyroAvailable { s += "G" }
    if motionManager.isMagnetometerAvailable { s += "M" }
    if motionManager.isDeviceMotionAvailable { s += "D" }
    if s == "" {
        availability.text = "Motion sensors: none"
    } else {
        availability.text = "Motion sensors: " + s
    }
}
```

DEPAUL UNIVERSITY

48

Sensors – Push

Handle Accelerometer

```
override func viewDidAppear(_ animated: Bool) {
    super.viewDidAppear(animated)
    let queue = OperationQueue()
    if motionManager.isAccelerometerAvailable {
        let accelStart = Date()
        var accelCount = 0
        motionManager.accelerometerUpdateInterval = 1/10
        motionManager.startAccelerometerUpdates(to: queue) {
            data, error in
            Handle acceleration data ...
        }
    } else {
        accelValue.text = "Accelerometer not available"
    }
}
```

DEPAUL UNIVERSITY

49

Sensors – Push

The Handler for Accelerometer

```
motionManager.accelerometerUpdateInterval = 1/10
motionManager.startAccelerometerUpdates(to: queue) { data, error in
    accelCount += 1
    let accel: String
    if let data = data {
        accel = String(format: "x=%+.3f y=%+.3f z=%+.3f",
                      data.acceleration.x, data.acceleration.y, data.acceleration.z)
    } else {
        accel = "No accelerometer data"
    }
    DispatchQueue.main.async {
        self.accelValue.text = accel
        let elapsedTime = Date().timeIntervalSince(accelStart)
        self.accelFreq.text = String(format: "%+.2fHz",
                                      Double(accelCount)/elapsedTime)
    }
}
...
```

DEPAUL UNIVERSITY

50

Sensors – Push

Handle Gyroscope

```
override func viewDidAppear(_ animated: Bool) {
    super.viewDidAppear(animated)
    ...
    if motionManager.isGyroAvailable {
        let gyroStart = Date()
        var gyroCount = 0
        motionManager.gyroUpdateInterval = 1/10
        motionManager.startGyroUpdates(to: queue) {
            data, error in
            Handle gyroscope data ...
        }
    } else {
        gyroValue.text = "Gyroscope not available"
    }
}
```

DEPAUL UNIVERSITY

51

Sensors – Push The Handler for Gyroscope

```
motionManager.gyroUpdateInterval = 1/10
motionManager.startGyroUpdates(to: queue) { data, error in
    gyroCount += 1
    let gyro: String
    if let data = data {
        gyro = String(format: "x=%+.3f y=%+.3f z=%+.3f",
                      data.rotationRate.x, data.rotationRate.y, data.rotationRate.z)
    } else { gyro = "No gyroscope data" }
    DispatchQueue.main.async {
        self.gyroValue.text = gyro
        let elapsedTime = Date().timeIntervalSince(gyroStart)
        self.gyroFreq.text = String(format: "%4.2fHz",
                                     Double(gyroCount)/elapsedTime)
    }
}
...
```

DEPAUL UNIVERSITY

49

Sensors – Push Stop Updates

```
override func viewWillDisappear(_ animated: Bool) {
    super.viewWillDisappear(animated)
    if motionManager.isAccelerometerActive {
        motionManager.stopAccelerometerUpdates()
    }
    if motionManager.isGyroActive {
        motionManager.stopGyroUpdates()
    }
    ...
}
```

DEPAUL UNIVERSITY

50

Sensors – Pull

- A simple demo app to display sensor data
 - Accelerometer
 - Gyroscope
 - Magnetometer
 - Device Motion
- Using the *pull* approach
 - Show sensor readings in text labels



DEPAUL UNIVERSITY

51

Sensors – Pull

```
import UIKit
import CoreMotion

class ViewController: UIViewController {
    let motionManager = CMMotionManager() must be declared as a property
    var timer: Timer?
    var timeStart = Date()
    var count = 0

    override func viewDidLoad() { ... }
    override func viewWillAppear(_ animated: Bool) { ... }
    override func viewWillDisappear(_ animated: Bool) { ... }
    ...
}
```

DEPAUL UNIVERSITY

52

Sensors – Pull Start Updates

```
override func viewWillAppear(_ animated: Bool) {
    super.viewWillAppear(animated)
    if motionManager.isAccelerometerAvailable {
        motionManager.accelerometerUpdateInterval = 1/10
        motionManager.startAccelerometerUpdates()
    } else { accelValue.text = "Accelerometer not available" }
    ...
    timeStart = Date()
    count = 0
    timer = Timer.scheduledTimer(timeInterval: 1/10, target: self,
                                 selector: #selector(handleSensors),
                                 userInfo: nil, repeats: true)
}
```

DEPAUL UNIVERSITY

53

Sensors – Pull The Handler

```
func handleSensors(_ timer: Timer) {
    count += 1
    let elapsedTime = Date().timeIntervalSince(timeStart)
    let freq = Double(count)/elapsedTime
    if motionManager.isAccelerometerAvailable {
        let accel: String
        if let data = motionManager.accelerometerData {
            accel = String(format: "x=%+.3f y=%+.3f z=%+.3f",
                           data.acceleration.x, data.acceleration.y, data.acceleration.z)
        } else {
            accel = "No accelerometer data"
        }
        self.accelValue.text = accel
        self.accelFreq.text = String(format: "%4.2fHz", freq)
    }
    ...
}
```

DEPAUL UNIVERSITY

54

Sensors – Pull Stop Updates

```
override func viewWillDisappear(_ animated: Bool) {
    super.viewWillDisappear(animated)
    if motionManager.isAccelerometerActive {
        motionManager.stopAccelerometerUpdates()
    }
    if motionManager.isGyroActive {
        motionManager.stopGyroUpdates()
    }
    ...
    timer?.invalidate()
}
```

DEPAUL UNIVERSITY

55

58

Device Attitude

- The orientation of a device
 - In three dimensional space
 - Relative to an external reference frame
- Are you interested in
 - the relative changes in device attitude?
 - or the true orientation?



DEPAUL UNIVERSITY

57

60

Reference Frame CMAttitudeReferenceFrame

- .xArbitraryZVertical**
 - X-axis points to an “arbitrary” direction.
 - Fixed to the orientation of the device when you *first* start device motion updates.
 - Most energy efficient option.
- .xArbitraryCorrectedZVertical**
 - Same as above with improved long-term yaw accuracy.
 - Uses the magnetometer, when available and calibrated, to correct bias in gyroscope.
 - Increased CPU usage and power consumption.

DEPAUL UNIVERSITY

59

62

Device Motion

- Class **CMDeviceMotion**
 - Sensor fusion: accelerometer + gyroscope + magnetometer
 - Processed motion data, highly accurate
 - Calibrated and corrected for bias
- Properties:


```
var attitude: CMAttitude { get }
var rotationRate: CMRotationRate { get }
var gravity: CMAcceleration { get }
var userAcceleration: CMAcceleration { get }
var magneticField: CMCalibratedMagneticField { get }
```

DEPAUL UNIVERSITY

56

59

Reference Frames of Attitude

- You choose the initial reference frame
- The attitude reading is relative to the initial reference frame
- The initial reference frame assumes
 - A device lying on a flat, i.e., horizontal, surface; face up
 - X-Y axes are on a horizontal plane
 - Z-axis is vertical, points up, i.e., towards the sky
- Which direction does the X-axis point to?
 - Impact on the accuracy and power consumption**

DEPAUL UNIVERSITY

58

61

Reference Frame CMAttitudeReferenceFrame

- .xMagneticNorthZVertical**
 - X-axis points to the magnetic north.
 - Uses the magnetometer. Requires calibration of the magnetometer.
 - Increased CPU usage and power consumption.
- .xTrueNorthZVertical**
 - X-axis points to the true north
 - Requires the magnetometer and the location data (GPS) to calculate the difference between magnetic and true north.
 - Most costly in CPU usage and power consumption.

DEPAUL UNIVERSITY

60

63

Reference Frame – True North

DEPAUL UNIVERSITY

64

Earth's Magnetic Field

DEPAUL UNIVERSITY

65

Geographic North Pole vs. Magnetic North Pole

DEPAUL UNIVERSITY

66

Magnetometer Data

- Class **CMLocalizedMagneticField**
 - Property
`var accuracy: CMMagneticFieldCalibrationAccuracy`
 - Property
`var field: CMMagneticField`
- Accuracy of magnetic field measurement
`enum CMMagneticFieldCalibrationAccuracy { case uncalibrated, case low, case medium, case high }`

DEPAUL UNIVERSITY

67

Magnetometer Data

- Struct **CMMagneticField**
 - Properties:
`var x: Double`
`var y: Double`
`var z: Double`
- Measured in *microteslas* (μT): strength of magnetic field
 - 31.869 μT : strength of Earth's magnetic field at 0° latitude, 0° longitude

DEPAUL UNIVERSITY

68

Attitude Data

- Class **CMAccuracy**
 - Properties:
`var roll: Double`
`var pitch: Double`
`var yaw: Double`
 - Euler angles measured in radians ($\approx 57.2958^\circ$)
- `var rotationMatrix: CMRotationMatrix`
Rotation matrix – a 3×3 matrix
- `var quaternion: CMQuaternion`
Quaternion – a 4-dimensional vector

DEPAUL UNIVERSITY

69

Euler Angles

- Roll, pitch, yaw
- Intuitive
 - Easily visualized
 - Familiar to user

DEPAUL UNIVERSITY

71

Demo: Always Up

- Hold device in up-right position
- Turn on a vertical plane
- The arrow maintains upward position
- Using gravity on X-Y plane

DEPAUL UNIVERSITY

72

Demo: Always Up

- Hold device in up-right position
- Turn on a vertical plane
- The arrow maintains upward position
- Using gravity on X-Y plane

DEPAUL UNIVERSITY

73

Demo: Always Up – Drawing the Arrow

```
class UpArrow: UIView {
    override func draw(_ rect: CGRect) {
        if let context = UIGraphicsGetCurrentContext() {
            let tip = CGPoint(x: bounds.width / 2, y: bounds.height * 0.1)
            let center = CGPoint(x: bounds.width / 2, y: bounds.height / 2)
            let left = CGPoint(x: bounds.width * 0.1, y: bounds.height * 0.9)
            let right = CGPoint(x: bounds.width * 0.9, y: bounds.height * 0.9)

            context.moveTo(to: tip)
            context.addLine(to: left)
            context.addLine(to: center)
            context.addLine(to: right)
            context.closePath()

            context.setFillColor(UIColor.green.cgColor)
            context.fillPath()
        }
    }
}
```

DEPAUL UNIVERSITY

74

Demo: Always Up – The Gravity Reading

```
class ViewController: UIViewController {
    @IBOutlet weak var arrow: UpArrow!
    let motionManager = CMMotionManager()
    let updateFrequency = 60.0

    override func viewDidAppear(_ animated: Bool) {
        super.viewDidAppear(animated)
        if motionManager.isDeviceMotionAvailable {
            motionManager.deviceMotionUpdateInterval = 1/updateFrequency
            motionManager.startDeviceMotionUpdates(to: .main) { data, error in
                if let gravity = data?.gravity {
                    let rotation = atan2(gravity.x, gravity.y) - Double.pi
                    self.arrow.transform =
                        CGAffineTransform(rotationAngle: CGFloat(rotation))
                }
            }
        }
    }
}
```

DEPAUL UNIVERSITY

75

Vector and Trigonometry

- A vector has an angle and a magnitude
- The magnitude of a vector

$$\sqrt{x^2 + y^2 + z^2}$$

$$\text{sqrt}(x * x + y * y + z * z)$$
- The tangent function

$$\tan \theta = \frac{y}{x}$$
- The inverse tangent function

$$\theta = \arctan \frac{y}{x}$$

DEPAUL UNIVERSITY

76

Arctangent Function in Swift

- Two options:


```
func atan(_ a: CGFloat) -> CGFloat
      Result: (-π/2, π/2)
```


Half a circle
- ```
func atan2(_ x: CGFloat, _ y: CGFloat) -> CGFloat
 Result: (-π, π]
```

Full circle
- Equivalent *some of the time*
 $\text{atan}(y / x) = \text{atan2}(y, x)$ 
  - If  $y > 0$  and  $x \neq 0$
  - $\text{atan}$  is limited to 2 quadrants.
  - $\text{atan2}$  supports all four quadrants.
  - $\text{atan2}$  works on all values of  $x$  and  $y$ , including when  $x = 0$

DEPAUL UNIVERSITY

73

## Arctangent Function in Swift



DEPAUL UNIVERSITY

74

## Demo: Always Up – Stop Updates & No Auto Rotate

```
class ViewController: UIViewController {
 override func viewWillDisappear(_ animated: Bool) {
 super.viewWillDisappear(animated)
 if motionManager.isDeviceMotionActive {
 motionManager.stopDeviceMotionUpdates()
 }
 }


 override var shouldAutorotate: Bool { return false }
}
```

DEPAUL UNIVERSITY

75

## Demo: Compass

- Hold device in horizontal position
- The arrows point to N-E-S-W
- Using the magnetic field on X-Y plane



DEPAUL UNIVERSITY

76

## Demo: Compass

```
class ViewController: UIViewController {
 @IBOutlet weak var compassView: CompassView!
 let motionManager = CMMotionManager()

 override func viewDidAppear(_ animated: Bool) {
 if motionManager.isDeviceMotionAvailable {
 motionManager.deviceMotionUpdateInterval = 1/10
 motionManager.startDeviceMotionUpdates(
 using: .xTrueNorthZVertical, to: .main) { data, error in
 if let mdata = data?.magneticField.field {
 self.compassView.transform =
 CGAffineTransform(rotationAngle:
 CGFloat(atan2(mdata.x, mdata.y)))
 }
 }
 }
}
```

DEPAUL UNIVERSITY

77

## Process Raw Sensor Data

81

82

## Filters for Raw Acceleration Data

- The raw accelerometer data was jittery, i.e., noisy.
  - Gravity, user action, environment,
- Filters can be applied to
  - Smooth out noises
- Isolate specific behaviors, e.g.,
  - The gravity – constant
  - User action – sudden, variable

 DEPAUL UNIVERSITY



83

## Low-Pass Filter

- A low-pass filter weighs the previous readings more than the current.
- A low pass filter has the effect of changing slowly based on the current raw data reading.
  - smoothing out sudden changes
  - isolates constant acceleration, i.e., gravity

 DEPAUL UNIVERSITY

80

84

## Low-Pass Filter

- A simple low-pass filter
- ```
filteringFactor = 0.1
value = currentReading * filteringFactor +
        previousValue * (1.0 - filteringFactor)
previousValue = value
```
- 10% current reading, 90% previous readings

 DEPAUL UNIVERSITY



85

High-Pass Filter

- A high-pass filter weighs the current readings more than the previous
- A high pass filter has the effect of changing rapidly based on the current raw data reading.
 - highlighting sudden changes, i.e., user movement

 DEPAUL UNIVERSITY

82

86

High-Pass Filter

- A simple high-pass filter
- ```
filteringFactor = 0.1
lowPassValue = currentReading * filteringFactor +
 previousValue * (1.0 - filteringFactor)
value = currentReading - lowPassValue;
previousValue = lowPassValue;
```
- current reading – smoothed value (obtained by low-pass filter)

 DEPAUL UNIVERSITY



87

## Sample Code

- Shaking – Shaking gesture
- Orientation – Device orientation changes
- Sensor – Push – All motion sensors
- Sensor – Pull – All motion sensors
- Always Up – Device Motion, Gravity
- Compass Demo – Device Motion, Magnetic Field
- Accelerometer Graph – Filters

 DEPAUL UNIVERSITY

84

88

**Next ...**

---

- Location and maps

◊ iOS is a trademark of Apple Inc.

---

 DEPAUL UNIVERSITY

89